

# PARTS LIST SUPPLEMENT

for the

# SUNBEAM "260"

Commencing Chassis Number

B9470001

This Supplement to be inserted at the front of the Sunbeam Alpine parts list No. 6600992, and to be used in conjunction with parts list No. 6600992.

Sales and Service in 163 Countries

---

Issued by

ROOTES MOTORS (PARTS) LTD., BIRMINGHAM 10

---

A ROOTES PRODUCT



# INDEX TO SECTIONS

For Descriptive Index see page iv

ENGINE (Motor)	AF
PETROL (Fuel) PUMP	BF
CARBURETTOR	CF
CARBURETTOR CONTROLS	DF
CLUTCH AND CONTROLS	FF
GEARBOX (Transmission) UNIT and GEAR SHIFT CONTROL	GF
SUSPENSION — FRONT	MF
AXLE — REAR and ROAD WHEELS	NF
PROPELLOR SHAFT	PF
BRAKES AND CONTROLS	QF
STEERING and CONTROLS	RF
SUSPENSION — REAR	SF
RADIATOR	TF
PETROL (Fuel) SYSTEM	UF
EXHAUST SYSTEM	VF
ELECTRICAL EQUIPMENT	WF
BODY MOUNTING	XF
BODY FITTINGS	YXF
SPECIAL ACCESSORIES	ZUF
TOOLS	ZVF
PARTS and SERVICE PUBLICATIONS	ZXF
NUMERICAL INDEX	ZZF

I  
N  
D  
E  
X

# INDEX

	Page No.		Page No.
<b>AXLE — REAR AND ROAD WHEELS</b>		<b>ENGINE (Motor)—continued</b>	
Axle Casing ... ..	NF1	Mountings—Engine (Motor) ... ..	AF7
Axle Shaft ... ..	NF1	Oil Filter Element ... ..	AF4
Crown Wheel (Ring Gear) and Bevel Pinion	NF1	Oil Pump ... ..	AF3
Differential Components ... ..	NF1	Pistons ... ..	AF1
Driver Coupling (Companion Flange) ...	NF1	Rocker Arm ... ..	AF5
Hubs c/w Bolts ... ..	NF2	Suction Pipe—Distributor Auto Control ...	AF6
Road Wheels ... ..	NF2	Sump ... ..	AF4
Panhard Rod ... ..	NF2	Thermostat ... ..	AF5
Wheel Trim ... ..	NF2	Timing Cover ... ..	AF1
<b>BODY FITTINGS</b> ... ..	YXF1 - YXF2	Water Pump ... ..	AF5
<b>BODY MOUNTING</b> ... ..	XF1	Ventilation—Crankcase ... ..	AF7
<b>BRAKES AND CONTROLS</b>		<b>EXHAUST SYSTEM</b> ... ..	VF1
Brake Fluid ... ..	QF1	<b>GEARBOX (Transmission) UNIT</b>	
Brake Pipes ... ..	QF1	1st Speed Wheel ... ..	GF1
Brake Pedal ... ..	QF1	2nd Speed Wheel ... ..	GF1
Hose ... ..	QF1	3rd Speed Wheel ... ..	GF1
<b>CARBURETTOR</b> ... ..	CF1 - CF3	Baulking Rings ... ..	GF1
Gasket Set ... ..	CF3	Cross Tube, Rear Engine Mounting ...	GF3
Repair Kit ... ..	CF3	Gearshift Lever Assembly ... ..	GF3
Tune-up Kit ... ..	CF3	Insulator—Rear Mounting ... ..	GF3
<b>CARBURETTOR CONTROLS (R.H.D.)</b> ...	DF1	Layshaft Cluster (Countershaft Gears) ...	GF1
<b>CARBURETTOR CONTROLS (L.H.D.)</b> ...	DF2	Mainshaft ... ..	GF1
<b>CLUTCH AND CONTROLS</b>		Input (Primary) Shaft (Stemwheel) ...	GF1
Clutch Cover ... ..	FF1	Reverse Idler Wheel (Gear) ... ..	GF1
Clutch Pedal ... ..	FF1	Rods—Gear Shift ... ..	GF3
Master Cylinder ... ..	FF1	Selector Forks ... ..	GF2
Slave Cylinder ... ..	FF1	Speedometer Cables ... ..	GF2
<b>ELECTRICAL EQUIPMENT</b>		Speedometer Driving Wheel (Gear) ...	GF1
Battery ... ..	WF4	Speedometer Driving Pinion ... ..	GF2
Cables and Grommets ... ..	WF4	Top Cover ... ..	GF2
Distributor ... ..	WF3 - WF4	<b>NUMERICAL INDEX</b> ... ..	ZZF1 - ZZF5
Dynamo (Generator) ... ..	WF3	<b>PARTS AND SERVICE PUBLICATIONS</b> ...	ZXF1
Horn ... ..	WF4	<b>PETROL (Fuel) PUMP</b> ... ..	BF1 - BF2
Ignition Coil ... ..	WF4	Mountings ... ..	BF2
Instruments ... ..	WF1	<b>PETROL (Fuel) SYSTEM</b> ... ..	UF1
Spark Plugs ... ..	WF4	<b>PROPELLOR SHAFT</b> ... ..	PF1
Starter (Motor) ... ..	WF2	<b>RADIATOR</b> ... ..	TF1
Starter Relay ... ..	WF1	<b>SUSPENSION — FRONT</b>	
Voltage Regulator ... ..	WF1	Coil Spring ... ..	MF1
<b>ENGINE (Motor)</b>		Crossmember ... ..	MF1
Air Cleaner ... ..	AF6	Lower Links ... ..	MF1
Big End Bearing ... ..	AF1	Steering Arms ... ..	MF1
Conn. Rod ... ..	AF1	<b>SUSPENSION — REAR</b>	
Camshaft ... ..	AF3	Shock Absorber ... ..	SF1
Camshaft Bearing Kit ... ..	AF3	Spring—Road ... ..	SF1
Crankshaft ... ..	AF3	<b>STEERING AND CONTROLS</b>	
Cylinder Block ... ..	AF1	Cowls—Steering Column ... ..	RF2
Cylinder Head ... ..	AF4	Handwheel ... ..	RF1
Exhaust Valve ... ..	AF4	Rack and Pinion ... ..	RF1
Fan Belt ... ..	AF6	Support Bracket ... ..	RF1
Fan Blade ... ..	AF6	Universal Steering Joint ... ..	RF1
Flywheel and Starter Ring (Gear) ...	AF3	Upper Column ... ..	RF1
Gasket Sets ... ..	AF8	<b>SPECIAL ACCESSORIES</b> ... ..	ZUF1
Inlet Valve ... ..	AF4	<b>TOOLS</b> ... ..	ZVF1
Main Bearing Set ... ..	AF1 - AF2		
Manifolds ... ..	AF5		